



C2C-11804-PR 2004 & UP XJ8 MESH INSERT INSTRUCTIONS

- Step 1: Remove grille assembly
- Step 2: Remove air duct assemblies from grille surround
- Step 3: Remove vanes from grille surround
- Step 4: Insert mesh with cutouts at the bottom.
*** NOTICE*** Significant force is needed to push the inserts into the grille surround.
- Step 5: Re-insert air duct assemblies and reinstall grille to vehicle

