



BCC-2829 INSTALLATION TIPS FOR 1/4" NYLON HOSES

INSTALLATION TIPS FOR 1/4" NYLON HOSES

1. Try to lay new hoses along same path as original hoses.
2. Do not bend or kink hoses during installation. Guarantee does not cover installer mistakes.
3. Make sure hoses will not be crushed by the folding top.
4. Install hoses so as to avoid hose striking obstacles as the cylinder travels (see illustration).
5. After installing hoses to pump/motor and cylinder, bleed the air out of the system with the FLUID-MATIC (or follow shop manual instructions for your car).
6. If re-using old original hose, clean all end fittings (threads & seating surfaces) thoroughly with a wire brush to ensure good seal and to prevent cross threading.
7. Insert and tighten fittings in cylinder USING ONLY FINGERS (to prevent cross threading). Then tighten 1/4 turn with wrench. Further tightening can break the cylinder port.

CROSS THREADING, STRIPPED THREAD OR BROKEN CYLINDER PORTS ARE SYMPTOMS OF INSTALLER ERROR AND ARE NOT COVERED BY GUARANTEE.

