



C2N-2752 XK8 2001 to 2005 Mesh Grille Instructions

- Step 1: Remove plastic push pins located at the top of the overrides. There will be two on each.
- Step 2: Gently squeeze the bottom bumper cover to remove overrides
- Step 3: Remove grille bolts. There is one on each end of the grille
- Step 4: Place mesh grille up to the car to determine metal screw placement onto the override brackets. Drill holes in override brackets and screw the grill onto brackets with screws. For 2004 and up models, use the pre-made screw placement spots already installed in mesh to mount onto your car.

