



FITTING INSTRUCTIONS, INSTRUCTIONS DE MONTAGE,
EINBAUANLEITUNG, ISTRUZIONI DI MONTAGGIO,
INSTRUCCIONES DE MONTAJE, 取扱説明書

XF

Bonnet Leaper

Bonnet Leaper

Jaguar accessory fitting instructions can be found at the URL below:
Les instructions de montage Jaguar sont disponibles à l'adresse Web ci-dessous :
Zu Einbauanweisungen für Jaguar-Zubehörteile siehe nachstehende URL:
Las instrucciones de montaje de accesorios de Jaguar se pueden encontrar en el URL siguiente:
Le istruzioni di montaggio accessori Jaguar si trovano all'indirizzo riportato qui sotto:

www.jaguartechno.com/extfree2viewjagprod/index.jsp

MY 2008.25

Part No.

8X23-669M0-AA


C2Z 1126



FITTING INSTRUCTIONS, INSTRUCTIONS DE MONTAGE,
EINBAUANLEITUNG, ISTRUZIONI DI MONTAGGIO,
INSTRUCCIONES DE MONTAJE, 取扱説明書

XF

Bonnet Leaper




VFAG4115

Contents of Kit

- A. Bonnet Leaper
- B. Drill Jig
- C. Bonnet Spreader Plate
- D. Drilling Template

Tools Required (Not Included in Kit)

- T1. Q-Max Cutter (40 mm)
- T2. Q-Max Cutter (17.5 mm)



Attention

Exposed surfaces must be treated against corrosion.
Refer to Body & Paint Repair (JJM 10 32 99) and
Category 'B' Supplement to Body &
Paint Repair Manual (JJM 99 44 21/30B) on GTR.

MY 2008.25

Part No.


8X23-669M0-AA

C2Z 1126

XF

Bonnet Leaper

1




VFAR3183

Notes .


2. Repeat for other side.

2




VFAG4141

3




VFAG4142

4




VFAG4140

5



VFAR3185

6



VFAG4138

MY 2008.25








Part No.

8X23-669M0-AA

C2Z 1126

XF


Bonnet Leaper



XF

Bonnet Leaper

13





VFAG4124

Hint!:


13. When fitting drill jig B, place drill jig over forward most stud first, and work jig down onto the second stud, until flush with inner bonnet skin.

14




VFAR3187

15





VFAR3214

16



VFAG4126






17





VFAG4127

XF

Bonnet Leaper



Attention
 Exposed surfaces must be treated against corrosion.
 Refer to Body & Paint Repair (JJM 10 32 99) and
 Category 'B' Supplement to Body & Paint Repair Manual
 (JJM 99 44 21/30B) on GTR.












FITTING INSTRUCTIONS, INSTRUCTIONS DE MONTAGE,
EINBAUANLEITUNG, ISTRUZIONI DI MONTAGGIO,
INSTRUCCIONES DE MONTAJE, 取扱説明書

XF

Bonnet Leaper



MY 2008.25

8X23-669M0-AA
Part No. C2Z 1126



FITTING INSTRUCTIONS, INSTRUCTIONS DE MONTAGE,
EINBAUANLEITUNG, ISTRUZIONI DI MONTAGGIO,
INSTRUCCIONES DE MONTAJE, 取扱説明書


XF

Bonnet Leaper

Notes .


31. Repeat for other side.

32



VFAG4145

33



VFAR3193